



### Step 3

Main menu screen -> Free Mixer

M1 (Mixer 1) – setting for normal aileron function (mixing channel 2 as master and channel 6 as slave)

M1 row – highlight first column (master channel) „??” – scroll to „ar”

M1 row – highlight second column (slave channel) „??” – scroll to „6”

Completed

### Step 4

Main menu screen - > Free Mixer

M2 (Mixer 2) – mixing of channel 5 (master) and channel 6 (slave) for thermal flap operation

M2 row – highlight first column (master channel) „??” – scroll to „5”

M2 row – highlight second column (slave channel) „??” – scroll to „6”

Completed